




# Midland X-tra Talk Radio LXT118 Circuit Board Replacement

How to get that fixed circuit board back in the radio!

Written By: James Tucker Dunn



## INTRODUCTION

It will be necessary to solder the wire connection in order to properly complete this installation.



### TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [Soldering Station](#) (1)
- [Spudger](#) (1)
- [Flush Wire Cutters](#) (1)



### PARTS:


- [Midland X-tra Talk Radio LXT118 Circuit Board](#) (1)

## Step 1 — Circuit Board



- Remove the old or broken circuit board from the front case.
- Clip the red and black wires at the base of the motherboard to completely separate it from the radio case.

## Step 2 — Circuit Board



- Reattach the speaker wires and antenna to the new circuit board using a soldering iron. Take caution when using the *hot* soldering tool!

To reassemble your device, follow these instructions in reverse order.